

1. Objective and Scope

To describe how to correctly install Saferoads Semi Mountable Kerbing.

2. Safety: 

Working on or beside a roadway is inherently dangerous.

3. Personal protective equipment (PPE)

The following is mandatory PPE.



Boots



Eye Protection



Ear Protection



Hi Viz



Gloves



Protective Clothing

4. Equipment Required

- a) Compressor with Air Nozzle;
- b) Hammer Drill and Bits;
- c) Industrial vacuum Cleaner;
- d) Generator;
- e) Epoxy and gun (refer SDS); and
- f) Chemwatch 4918-30.

5. Qualifications and Competencies

- a) Safe use of hand tools;
- b) Manual handling; and
- c) Road traffic management.

6. Documentation and Setup

- a) Ensure that the selected installer provides a copy of Public Liability Insurance, WorkCover, SWMS and plant service records. (No documentation - no job).

- b) Contact Dial before you Dig; if required (recommended)



- c) Ensure you are at the correct location and set up traffic control is to Australian Standards, or as advised and required by the client.

7. Positioning of Semi Mountable Kerbing

- a) Position the Semi Mountable Kerbing on to a cleaned road surface, as per site plan provided.



8. Fastening to pavement

- a) Using a drill with a 14mm masonry bit, drill 120mm deep holes through the designated points in the speed hump.



- b) Slide out one segment at a time. Using an industrial vacuum cleaner or air gun remove dust from each hole. Note: if using air gun be careful of airborne dust and stones.



- c) Using epoxy and caulking gun, insert nozzle into each hole and insert epoxy. Saferoads recommends 3 caulks per hole. Note: the epoxy dries quickly in warm weather so it is important to cap the nozzle with cling wrap between uses to prevent it from drying hard inside the nozzle



- d) Insert the nylon plug into each hole using a hammer. Note: be careful of splatter of any excess epoxy when hammering.



- e) Quickly re-instate the segment into the correct position, lining up the fastener holes. Note: the epoxy can set hard quickly in warm weather making it difficult to screw in the coach bolt.

- f) Insert the coach bolt and hand tighten.



- g) Using air compressor and a rattle gun or a drill with a 17mm socket, screw in the coach bolt, being careful not to tighten it all the way. Note: the coach bolt will rotate the plastic sleeve in the holes if over tightened mechanically. This will undermine the epoxy adherence to the side walls of the hole, rendering it ineffective.



- h) Finish tightening coach bolts using a ratchet socket wrench with a 17mm socket. Note: ensure this step is completed quickly as the epoxy will set too hard preventing tightening of the bolt.





9. Insert rubber plug

- a) Insert the rubber plugs into the holes.

10. Finish

- a) Sweep up any excess dirt or debris from the site and collect any left-over parts.

11. House Keeping and Final Checks

a) Safety Checks:

- Housekeeping practices adhered to and worksite is left clean and safe; and
- Items have been fitted correctly and safely.

b) Quality Checks:

- Workmanship is to specification;
- Materials quality is acceptable;
- Unused materials are removed; and
- Quality checks performed.

c) Environment Checks:

- Surrounds are restored to prior condition; and
- No spillage and/or damage to any soil, habitat, atmosphere or drainage

SOP REVISION UPDATES

Rev 5 dated 08/10/2020

- a) New format

Rev 4 dated 05/04/2018

- a) New format
- b) Inclusion of Revision Details.
- c) Reference included for Housekeeping and Final Checks